


4-LED LIGHTHEAD



FLASH PATTERN

- 0 Random (default)
- 1 Single (split)
- 2 Double (split)
- 3 Quad (split)
- 4 Quint (split)
- 5 Mega (split)
- 6 Ultra (split)
- 7 Single-Quad (split)
- 8 Single H/L (split)
- 9 Single (all)
- 10 Double (all)
- 11 Quad (all)
- 12 Quint (all)
- 13 Mega (all)
- 14 Ultra (all)
- 15 Single-Quad (all)
- 16 Single H/L (all)
- 17 Steady 2 (california)
- 18 Steady 4 (all)

To select Flash Pattern,
apply +VDC to YELLOW wire:

- for less than 1 second for next pattern
- for more than 1 second for previous pattern
- for more than 5 seconds for reset to default