REMATCH (Not applicable to the ECO version)

STEP 2


Power the beacon up.

STEP 1



Unfasten the screws on the bottom.









LED BEACON

DIMENSIONS





REMOTE CONTROL

- With the beacon turned on, the control will be connected to function.
- Use the control within 35m from the product.
- Function Display



ON





Selection







HOW TO CHARGE THE PRODUCT

- 1. Connect the cigarette plug (included) to the cigarette lighter port in the vehicle (12V only).
- 2. Charge via 110-220V power with a universal power adapter (sold separately).
- 3. A 4-hour charge allows 8-hour duration.
- 4. A 3-hour charge allows 5-hour duration. (Applicable to the ECO version)

MOUNTING

• Magnetic Mount







Permanent Mount with 4 screws

• (Soon available) An iron sheet will be provided for vehicles with aluminum or glass roofs. Choose from adhesive tape, suction cups or velcro tapes to fasten and secure the product.

WIRING

3m long wire with an A13-54 cigarette plug (12V)

ON/OFF



FLASH PATTERNS 1. Ramdom(Default) 12. Quad(All)

5. Quint(Split)

6. Mega(Split)

7. Ultra(Split)

10. Single(All)

11. Double(All)

8. Single-Quad(Split)

9. Single-H/L(Split)

- Single(Split) 13. Quint(All) 3. Double(Split)
- 14. Mega(All) 15. Ultra(All) 4. Quad(Split)
 - 16. Single-Quad(All)
 - 17. Single-H/L(All)
 - 18. ECE 65 Double Flash Phase 1
 - 19. ECE 65 Double Flash Phase 2
 - 20. ECE 65 120FPM Single Flash Phase 1
 - 21. ECE 65 120FPM Single Flash Phase 2

 - 22. ECE 65 125FPM Rotator Flash