



Supplied with: Tower light, carry bag and USB charging cable.

Charging the floodlight



Charging Socket



Battery Charging and Status Indicators



4 hours charging time.

The light can be used continuously when plugged into suitable 5V 2A power source but it will only operate on medium mode.

Setting up the Tower Pro:




1. Push button switch to unlock the tripod legs



2. Slide the tripod legs down.




3. Unlock the two hand wheels and extend the pole. Re-tighten wheels.



4. Pull light heads from the bottom and rotate swivel to desired angle.

5. Press  button to turn the light ON/OFF again to change light modes: Low  Medium  High  Off



6. Use this button to change light beam from Cool white to Warm white



Removing the Tower Pro light head:

To use the hanging hook or magnetic base simple unscrew the light head from the tripod.



Hanging hook

Magnetic base



RAS
DISTRIBUTION
Rouler Alerte Signaler

www.ras-distribution.com
Tel: 04.67.60.49.68

