




Charging the floodlight



Charging Socket

Insert plug into socket and tighten hand wheel.



Battery Charging and Status Indicators



6 hours charging time.

The light can be used continuously when plugged into AC mains but it will only operate on medium mode.

Setting up the Tower Pro:




❶. Slide button and lift leg to unlock each leg.



❸. Unlock extending clamp and extend both poles to desired height and lock clamps.




❹. Pull out the light heads from the top handle and rotate swivel to desired angle.



❷. Unfold each leg out into position.



Setting up the Tower Pro Continued...

5. Press  button to turn the light ON/OFF again to change light modes:

Low → Medium → High → Off
5hrs 2.5hrs 1hrs




6. Use this button to change light beam from Cool white to Warm white



Built-in cable and charger wrapping system for tidy storage.

Reversible ground spikes:



The Tower Pro comes with ground spikes, ideal for using on uneven ground. To release these unscrew using a screw driver, pull out the spike and rotate and push back into hole to secure into place.



Product weight	4.5kg
Product size (mm)	122x160x890mm
NS Part No.	NSTOWERPRO-2K